

## Nya grundläggande funktioner

### Automatiskt språkval

Är SIM-kortet från en svensk operatör kommer YOYOCare automatiskt använda svenska som standardspråk.

Är det från annan operatör/annat land kommer YOYOCare använda engelska.

Ändras språket med kommandot LSSV eller LSEN kommer det valda språket gälla tills YOYOCare återställs eller tills LSxx kommandot används.

## Nya Master kommandon

### Meddelande om YOYOCare slås Av/På (standard är AV)

Master kan få en SMS-rapport varje gång YOYOCare slås av och på.

Rapporten som ges när YOYOCare slås på är:

**YOYO: PÅ 12:11 Jan 15 <http://maps.google.com...> (fix 09:34 Jan 15) (batt. 6)**

Rapporten som ges när YOYOCare stängs av är:

**YOYO: AV 12:11 Jan 15 <http://maps.google.com...> (fix 09:34 Jan 15) (batt. 6)**

- a) Fråga aktuell status: **POR?**  
Ex. Master skickar: **POR?**  
YOYOCare svarar: **YOYO: På- och Av-rapport - PÅ**
- b) Aktivera På- och Av-rapport: **POR1**  
Ex. Master skickar: **POR1**  
YOYOCare svarar: **YOYO: På- och Av-rapport – PÅ**
- c) Avaktivera På- och Av-rapport: **POR0**  
Ex. Master skickar: **POR0**  
YOYOCare svarar: **YOYO: På- och Av-rapport – AV**

**På- och Av-rapport skickas när den grå På/Av-knappen används för att slå på eller stänga av YOYOCare. Ingen notifiering sker om YOYOCare stängs av genom att batteriet tas ur.**

### Ring Master efter Larm-SMS skickats när SOS-larmknappen tryckts in (standard är AV)

När SOS-larmknappen trycks in skickar YOYOCare ett larmmeddelande och sedan kopplas ett röstsamtal upp till Masterns telefonnummer.

- a) Fråga aktuell status: **SOSV?**  
Ex. Master skickar: **SOSV?**  
YOYOCare svarar: **YOYO: Ring upp efter larmmeddelande – AV**
- b) Aktivera röstsamtal efter varningsmeddelande: **SOSV1**  
Ex. Master skickar: **SOSV1**  
YOYOCare svarar: **YOYO: Ring upp efter larmmeddelande - PÅ**
- c) Inaktivera röstsamtal efter varningsmeddelande: **SOSV0**  
Ex. Master skickar: **SOSV0**  
YOYOCare svarar: **YOYO: Ring upp efter larmmeddelande - AV**

### Knappfunktion Av/På (standard är PÅ)

De färgade knapparna 1, 2 och 3 samt SOS-larmknappen kan stängas av. Endast den grå på/av-knappen fungerar.

- a) Fråga aktuell status för knappsats: **KF?**  
Ex. Master skickar: **KF?**  
YOYOCare svarar: **YOYO: Snabbvals- och larmknapparna är PÅ**
- b) Aktivera knappsatsen: **KF1**  
Ex. Master skickar: **KF1**  
YOYOCare svarar: **YOYO: Snabbvals- och larmknapparna är PÅ**
- c) Inaktivera knappsatsen: **KF0**  
Ex. Master skickar: **KF0**  
YOYOCare svarar: **YOYO: Snabbvals- och larmknapparna är AV**

Nya funktioner från mars 2012. Ändringar kan ske utan föregående meddelande.

## ***New basic functionality***

### **Automatic language selection**

If the home country of the SIM card is Sweden then YOYOCare will automatically use Swedish as its default language.

If the SIM card is other than Swedish then it will use English as default.

If the language is changed by command LSSV or LSEN the chosen language will remain until YOYOCare is reset.

## ***New Master Commands***

### **Notification at Power Off and Power On (default is OFF)**

The Master can be notified by an SMS-report each time YOYOCare is turned off and on.

The report message when YOYOCare is turned on is:

**YOYO: ON 12:11 Jan 15 <http://maps.google.com>...(fix 09:34 Jan 15) (batt. 6)**

The report message when YOYOCare is turned off is:

**YOYO: OFF 12:11 Jan 15 <http://maps.google.com>...(fix 09:34 Jan 15) (batt. 6)**

- a) Check current status: **POR?**  
E.g. Master sends: **POR?**  
YOYOCare replies: **YOYO: Power ON and OFF reports - enabled**
- b) Activate on and off reporting: **POR1**  
E.g. Master sends: **POR1**  
YOYOCare replies: **YOYO: Power ON and OFF reports – enabled**
- c) Disable on and off reporting: **POR0**  
E.g. Master sends: **POR0**  
YOYOCare replies: **YOYO: Power ON and OFF reports – disabled**

Power on and off reports will be sent when the grey Power On/Off button is used to turn YOYOCare on or off. No notification will be sent if YOYOCare is turned off by removing the battery.

### **Call Master after sending Alert SMS upon pressing the Alert button (default is OFF)**

After pressing the Alert button YOYOCare will first send an Alert message and then make a voice call to the Master phone number.

- a) Check current status: **SOSV?**  
E.g. Master sends: **SOSV?**  
YOYOCare replies: **YOYO: Voice call after Alert message - OFF**
- b) Activate Voice call after Alert SMS is sent: **SOSV1**  
E.g. Master sends: **SOSV1**  
YOYOCare replies: **YOYO: Voice call after Alert message - ON**
- c) Disable Voice call after Alert SMS is sent: **SOSV0**  
E.g. Master sends: **SOSV0**  
YOYOCare replies: **YOYO: Voice call after Alert message - OFF**

### **Disable the Keypad Function of YOYOCare (default is ON)**

The coloured keys 1, 2 and 3 as well as the Alert button are disabled. Only the grey on/off button is operational.

- a) Check current keypad status: **KF?**  
E.g. Master sends: **KF?**  
YOYOCare replies: **YOYO: Quick-dial and Alert buttons are enabled**
- b) Activate the keypad: **KF1**  
E.g. Master sends: **KF1**  
YOYOCare replies: **YOYO: Quick-dial and Alert buttons are enabled**
- c) Disable the keypad: **KF0**  
E.g. Master sends: **KF0**  
YOYOCare replies: **YOYO: Quick-dial and Alert buttons are disabled**

New functions per March 2012. Subject to change without prior notice.

© YOYOMOTION AB, Sweden

[www.yoyomotion.com](http://www.yoyomotion.com)