

# YOYOCare P3 - User Guide Supplement

New functions from March 2012

## ***New basic functionality***

### **Automatic language selection**

If the home country of the SIM card is Sweden then YOYOCare will automatically use Swedish as its default language. If the SIM card is other than Swedish then it will use English as default. If the language is changed by command LSSV or LSEN the chosen language will remain until YOYOCare is reset.

## ***New Master Commands***

### **Notification at Power Off and Power On (default is OFF)**

The Master can be notified by an SMS-report each time YOYOCare is turned off and on.

The report message when YOYOCare is turned on is:

**YOYO: ON 12:11 Jan 15 <http://maps.google.com/maps...> (fix 09:34 Jan 15) (batt. 6)**

The report message when YOYOCare is turned off is:

**YOYO: OFF 12:11 Jan 15 <http://maps.google.com/maps...> (fix 09:34 Jan 15) (batt. 6)**

- a) Check current status: **POR?**  
E.g. Master sends: **POR?**  
YOYOCare replies: **YOYO: Power ON and OFF reports - enabled**
- b) Activate on and off reporting: **POR1**  
E.g. Master sends: **POR1**  
YOYOCare replies: **YOYO: Power ON and OFF reports – enabled**
- c) Disable on and off reporting: **POR0**  
E.g. Master sends: **POR0**  
YOYOCare replies: **YOYO: Power ON and OFF reports – disabled**

**Power on and off reports will be sent when the grey Power On/Off button is used to turn YOYOCare on or off. No notifications will be sent if YOYOCare is turned off by removing the battery.**

### **Call Master after sending Alert SMS upon pressing the Alert button (default is OFF)**

After pressing the Alert button YOYOCare will first send an Alert message and then make a voice call to the Master phone number.

- a) Check current status: **SOSV?**  
E.g. Master sends: **SOSV?**  
YOYOCare replies: **YOYO: Voice call after Alert message - OFF**
- b) Activate Voice call after Alert SMS is sent: **SOSV1**  
E.g. Master sends: **SOSV1**  
YOYOCare replies: **YOYO: Voice call after Alert message - ON**
- c) Disable Voice call after Alert SMS is sent: **SOSV0**  
E.g. Master sends: **SOSV0**  
YOYOCare replies: **YOYO: Voice call after Alert message - OFF**

## Disable the Keypad Function (Alert and Dial buttons) of YOYOCare (default is OFF)

The coloured keys 1, 2 and 3 as well as the Alert button are disabled. Only the grey on/off button is operational.

- a) Check current keypad status: **KF?**  
E.g. Master sends: **KF?**  
YOYOCare replies: **YOYO: Quick-dial and Alert buttons are enabled**
  
- b) Activate the keypad: **KF1**  
E.g. Master sends: **KF1**  
YOYOCare replies: **YOYO: ...**
  
- c) Disable the keypad: **KF0**  
E.g. Master sends: **KF0**  
YOYOCare replies: **YOYO: ....**

Power on and off reports can only be sent when the grey Power On/Off button is used but cannot send notifications if only the battery is removed.